




www.2Linc.com


## CNC Dot Peen Tool Stop Block Template to assist with mounting to CNC spindle

Catalog No.: 11410  
CNC Dot Peen Tool  
Stop Block - Large

Catalog No.: 11409  
CNC Dot Peen Tool  
Stop Block - Small



Distance to CNC  
Spindle Centerline  
2.17" (55mm), 2.56" (65mm), or  
3.15" (80mm)



Distance to CNC  
Spindle Centerline  
2.17" (55mm), 2.56" (65mm), or  
3.15" (80mm)

To use a CNC Dot Peen Tool, it is necessary to install a Stop Block to prevent rotation of the CNC Dot Peen Tool when the spindle is rotating. To determine which Stop Block will best fit your CNC machine, cut out each of the above templates and place them on the CNC spindle over its predrilled mounting holes.

To determine where to drill mounting holes in the Stop Block, simply press the cut out template onto the mounting holes that exist on your CNC spindle face. Pressing on the template will leave indentations that will show where to drill the holes into the Stop Block. Mounting screws may be placed anywhere except the areas marked with black. After the holes are drilled into the Stop Block, mount the Stop Block onto the spindle.

**2L inc. | 4 Kane Industrial Dr. | Hudson, MA 01749, USA**  
t: 978-567-8867 | f: 978-562-8972 | e: [contact@2Linc.com](mailto:contact@2Linc.com) | [www.2Linc.com](http://www.2Linc.com)